




MT610 Pro


Product Introduction

EN


Front View:



Rear View:




Accessories



Install the Print Paper


01 Open the top cover

Pull the cover-opening button up, and open the top cover.



02 Adjust separator

Pull the Separator, please adjust the separator according to the paper width.



Install the Print Paper


03 Close the top cover

Make sure the top cover is closed in place.



04 Put in the printing paper

Put the thermal paper face up into the paper inlet, and the paper will enter the paper automatically.




 Please use official thermal paper for a better printing experience.

Power On

01 Power on


Hold down the power button for 3 seconds to start the printer.



 To turn off the printer, also hold down the power button for 3 seconds.

Printing from PC

- 1 Connect one side of the USB cable to the PC and the other side to the printer.
- 2 Turn on the printer.
- 3 Download the printer driver from the website:
<https://www.hpvt.com/>
And then install it on the PC.
- 4 Choose the document you want to print from the PC and print it via printer
“HPRT MT610 Pro”.



Printing Wirelessly from Mobile Phone

01 Download App

Scan the QR code below to download App.



02 Connect with the printer

Turn on the Bluetooth on the phone, open the App, click "Connect printer", and "Connect" with "MT610 Pro-xxxx".


03 Print

- 1 Open the document you want to print, and copy/share it to App.
(Or select document printing on the App home page).
- 2 Adjust it in the print preview, and click the print icon on the top right corner to print.

 Note: App operation shall be subject to the latest version.

Battery Charging

When the battery is low, the operational status LED will flash (red light flashes quickly). Please use the matching USB cable to charge in time. If you continue printing, the printer may shut down automatically.



Precautions

- 1 The best operating temperature is 0°C~40°C, if the environmental temperature is too low or too high, the print quality may be affected.
- 2 Please do not use the unofficial paper roll to ensure the print quality.
- 3 During printing, the printer head will heat up, do not touch it to avoid burns.
- 4 Do not pull out the paper by force during printing, or else it may damage the printer.

Product Parameters

Product Name: Mobile Printer

Product Model: MT610 Pro

Battery Parameter: 7.4V, 2000mAh

Dimensions: 266 x 55 x 47mm

Weight: About 0.5kg (without accessories)

Operating Temperature: 0°C~40°C

Note: The illustrations of products, accessories, and user interface in the manual are for reference only. Due to product innovation and upgrade, the actual product may differ slightly from the illustrations, please refer to the actual product.



Please Scan QR Code to Get 24h After-sales Technical Support Service



Search “HPRT Official ” on YouTube to Get Instruction Videos



HPRT YouTube Website

Search “HPRT Official ” on Facebook to Get Extra Consumables of Printer



HPRT Facebook Website

Xiamen Hanin Co., Ltd.

E-mail: support@hpert.com

support02@idprt.com

Web: <https://www.hpert.com/>

US After-sales Hotline: 1-833-658-6166

Available on weekdays from 9:00 a.m. to 5:00 p.m.(PST)

