

Tablet User Manual

Quick Start Guide

****Charger Compatibility Requirements****

- Refer to the input voltage/current values on the back of the product you purchased.
- This product only supports chargers with the above specifications, and the charger must comply with Chinese national standards.
- If the device is not used for a long time, charge it once every three months, fully charge it, then turn it off and store it.
- For long-term stored devices, pre-charge with the charger for more than 30 minutes before the charging status is displayed.

****Precautions****

Thank you for purchasing Teclast products! This product is equipped with an Android smart operating system. This guide briefly introduces various functions of the product, allowing you to operate it smoothly and fully enjoy the value it brings. Please read this guide carefully before use.

1. Note that new batteries reach optimal performance only after two or three complete charge and discharge cycles.
2. To prevent data loss, it is recommended to regularly back up important data, especially before firmware upgrades or repairs. Our company is not responsible for losses caused by data loss.
3. This product is a high-precision electronic device; do not disassemble it yourself.
4. Avoid strong impacts, water drops, splashes, and collisions.
5. Avoid using the product in the following environments: high temperature, low air pressure, low temperature, humidity, dust, strong magnetic fields, and prolonged exposure to sunlight. We recommend using this product in an environment with an altitude below 3000 meters, temperature between 0° C and 35° C, and humidity between 5% and 95%.
6. Use batteries, chargers, and accessories permitted by the manufacturer. Using any other type of accessories will violate the warranty terms and may be dangerous.

****Friendly Tips****

- The nominal battery life of this product refers to the maximum battery life achievable in a minimum power consumption environment. Actual battery life may vary depending on usage and environmental factors (such as enabling Wi-Fi, Bluetooth, screen brightness, volume), as well as slight differences between individual products.
- The difference between the nominal and actual disk capacity of this product is due to:
 1. Calculation error: Hardware manufacturers calculate 1MB as 1000KB, while software calculates 1MB as 1024KB. For example, a product with a nominal capacity of 8GB, when converted for software recognition, is $8 \times 1000 \text{MB} \times 1000 \text{KB} \times 1000 \text{B} / 1024 \text{MB} / 1024 \text{KB} / 1024 \text{B} \approx 7.45 \text{GB}$, resulting in a 0.55GB calculation error. The larger the capacity, the greater the error.
 2. The Android operating system occupies part of the disk space.
- The nominal battery capacity of this product is calculated by the actual charge and discharge process, using third-party tools to detect the battery capacity. Due to current fluctuations, there will be a large error, so it is not used as a standard for judgment.

****Initial Setup Guide****

This guide will help you quickly select language, time zone, set up Wi-Fi network, user and computer name, and other information. Follow the prompts in the guide to personalize your setup and start your valuable experience.

****Welcome****

****Button Definitions****

- **Power Button:**

- In the off state, long press the power button for 3 seconds to turn on the device.
- In the on state, short press the power button to turn off the screen and put it to sleep. To activate the screen again, short press the power button.
- In the on state, long press the power button for 3 seconds to enter the shutdown prompt interface, long press for 10 seconds to force power off.

- ****Volume Up Button:**** Short press or long press to increase volume.

- ****Volume Down Button:**** Short press or long press to decrease volume.

****Home Button****

****Back Button****

****Recent Apps Button****

****Menu Button****

****Screenshot Button****

****Volume Up Button****

****Volume Down Button****

****Virtual Button Bar****

- Tap to return directly to the main interface
- Tap to go back to the previous interface
- Tap to view, switch, close background programs
- Tap to bring up menu options
- Tap to save the current screen image
- Short press or long press to increase volume
- Short press or long press to decrease volume
- Pull down the notification bar
- Tap to quickly switch the current user
- Tap to quickly bring up system settings
- Tap to quickly bring up battery settings
- Tap to quickly enable or disable Wi-Fi
- Tap to quickly enable or disable Bluetooth
- Tap to quickly adjust volume
- Tap to quickly enable or disable flight mode
- Tap to quickly enable or disable screen orientation lock
- Tap to quickly enable or disable location function
- Tap to quickly enable or disable search for wireless display devices

****Wi-Fi Wireless Connection****

1. Tap the "Settings" icon to enter the settings list, select "WLAN" or "Wi-Fi" to enter the Wi-Fi settings menu.
2. Slide the switch to turn on the Wi-Fi function, the system will automatically scan for nearby Wi-Fi hotspot signals.
3. Select and tap a Wi-Fi signal to connect, enter the corresponding password, and tap "Connect".

****SIM Card and Mobile Network Connection****

1. Insert the SIM card while the device is off, then turn on the device.
2. Tap the "Settings" icon to enter the settings list, select "Data usage" menu.
3. Slide the switch to turn on "Mobile data network".
4. The SIM card slot is under the white cover on the right side. Open the white cover to insert the card, ensuring the chip is facing down.

****Bluetooth Connection****

1. Tap the "Settings" icon to enter the settings list, select the "Bluetooth" menu.
2. Slide the switch to turn on Bluetooth, the system will automatically scan for nearby Bluetooth signals.
3. Select and tap a Bluetooth device to connect, in the "Bluetooth pairing request" pop-up, tap "Pair".
4. Once confirmed by the other device, the connection will be successful.

****Display Settings****

Tap the "Settings" icon to enter the settings list, select the "Display" menu.

1. Brightness: Adjust the screen backlight brightness by sliding the progress bar.
2. Wallpaper: Set the desktop wallpaper display content.
3. Sleep: Set the system to automatically turn off the screen after a period of inactivity.
4. Font Size: Set the system font size.
5. Auto-Rotate: Lock the current screen orientation, or automatically rotate the screen based on the device orientation.

****Sound Settings****

Tap the "Settings" icon to enter the settings list, select the "Sound & notification" menu.

1. Volume: Adjust media, alarm, and ringtone volume by sliding the progress bar.
2. Notification Ringtones: Set notification ringtones.
3. Phone Ringtones: Set incoming call ringtones.
4. Other Sounds: Enable or disable screen lock sound, touch sound.

****Battery Status Display****

Tap the "Settings" icon to enter the settings list, select the "Battery" menu to view battery usage status.

- Battery Percentage Display: Slide the switch to enable or disable battery percentage display.

****Cannot Turn On or Charge****

1. There is a small hole next to the power button; use a toothpick to press it, then long press the power button for ten seconds to turn on the device.
2. Charge the tablet for more than 30 minutes before pressing the power button to turn it on.

****App Management****

Tap the "Settings" icon to enter the settings list, select the "Apps" menu to manage applications: uninstall, clear defaults, clear cache, clear data, force stop.

1. Third-Party Apps: Can be uninstalled.
2. System Apps: Cannot be uninstalled.

****User Management****

Tap the "Settings" icon to enter the settings list, select the "User" menu.

1. Supports setting up multiple user logins.
2. Each user can set up their own personal applications and content.

****Location Information****

Tap the "Settings" icon to enter the settings list, select the "Location" menu.

1. Slide the switch to enable or disable location function.
2. Tap "Mode" to select the method of location.

****Security Settings****

Tap the "Settings" icon to enter the settings list, select the "Security" menu.

1. Screen Lock Method: Choose between swipe, pattern, PIN, and password screen lock methods.
2. Unknown Sources: Slide the switch to enable or disable the installation of local applications.

****Language and Input Method****

Tap the "Settings" icon to enter the settings list, select the "Language & input" menu.

1. Language: Switch the system language.
2. Input Method: Set the default input method and configure settings for each input method.

****Account Management****

Tap the "Settings" icon to enter the settings list, select the "Account" menu.

1. Add Account: Add accounts for applications in the system.
2. Manage existing accounts, including data synchronization.

****Factory Reset****

1. Tap the "Settings" icon to enter the settings list, select the "Backup & reset" menu, and choose "Factory data reset".
2. Factory reset will clear all user data (applications, local data, etc.), so be sure to back up important data.

****Date and Time****

Tap the "Settings" icon to enter the settings list, select the "Date & time" menu.

1. Automatic Date and Time: Slide the switch to enable automatic synchronization of date and time when connected to the network. Slide the switch off to manually set date and time.
2. Automatic Time Zone: Slide the switch to enable automatic synchronization of time zone when connected to the network. Slide the switch off to manually set time zone.
3. Use 24-Hour Format: Slide the switch to enable 24-hour time display.

****USB**

OTG Function**

The USB OTG function supports connecting this product to other mobile devices (U disk, 3G internet card, label printer, keyboard, etc.) for data exchange.

1. To use the USB OTG function, connect the mobile device and this product via an OTG cable.
2. When using the USB OTG function, ensure the battery level of this product is above 50%. For high-power mobile devices, use an independent power supply.

This is a translation of the key sections from the provided document. If there are specific sections or additional details you need translated, please let me know!