


User's Manual

V9 / V9 Pro - Gaming Headset

Friendly Reminder: The illustrations in this manual are for reference only and may differ from the actual product. Please refer to the physical product.



Power Button

Power On/Off: Press and hold for about 3s
Connection Mode Switch: Double press
Game/Music Mode Switch: Triple press
Play/Pause: Single press
Answer/End Call: Single press
Reject Call: Press and hold for about 1.5s



Indicator Light

Bluetooth Pairing Mode: Red & blue lights alternate flashing
2.4G Pairing Mode: Red & green lights alternate flashing
Charging: Red light stays steadily lit
Fully Charged: Blue light stays steadily lit




Microphone Button

Microphone On/Off: Single press



Volume Scroll Wheel

Volume Up: Scroll upward
Volume Down: Scroll downward



***Receiver pairing** (paired by default, factory settings): In 2.4G mode, press and hold the [Power Button] and [Microphone Button] simultaneously until the indicator flashes white 3 times. Insert the USB receiver into your computer, when the receiver's green light stays steady, it indicates that the 2.4G re-pairing is successful.

*For manual pairing, keep the headset as close as possible to the receiver.

M HUB Client Driver: <https://www.maicong.cn>


Open this URL in your browser

Click [Driver] → [Download M HUB Client] to install.

*Note: The M HUB client driver currently only supports Windows 10 or above. Windows 7 and macOS operating systems are not supported at this time.

V9 Pairing Name: MCHOSE V9

V9 Pro Pairing Name: MCHOSE V9 Pro



Friendly Reminder:

When the headset disconnects due to exceeding the Bluetooth range, it will automatically reconnect to the device upon returning within range. If no reconnection succeeds within 5 minutes, the headset will power off automatically.

Reset Bluetooth to factory settings: With the headset powered off in Bluetooth mode, press and hold for 8 seconds until the indicator light flashes white rapidly 3 times to confirm successful reset. The headset can then be available for pairing again. (If the original device has pairing records, please delete them manually).

Sound Card Mode



1. With the headset powered on, connect it to your computer via the USB cable to automatically switch to Sound Card Mode.
2. Double-press the  button to cycle between [Adapter Mode] / [Bluetooth Mode] / [Sound Card Mode].
3. Under 2.4G or Bluetooth mode, you may charge while gaming by connecting the charging cable.

Charging



Low Battery: Red indicator light flashes slowly
Charging: Red indicator light stays steadily lit
Fully Charged: Blue indicator light stays steadily lit

Note: This device has been tested and complies with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this device does cause harmful interference to radio/TV reception (determined by turning the device off/on), the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient/relocate the receiving antenna.
- Increase separation distance between the device and receiver.
- Connect the device to a power outlet on a different electrical circuit from the receiver.
- Consult the dealer or a qualified broadcast/TV technician for assistance.

Unauthorized modifications or alterations not expressly approved by the responsible compliance party may void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation shall be subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

 <p>Charging Instructions</p>	<ol style="list-style-type: none">1. Use only computer USB ports to charge the headset.2. Do not use fast-charging phone adapters to charge the headset.3. Do not use inferior non-standard power adapters to charge the headset.4. Do not use over-voltage or over-current power adapters to charge the headset.5. Keep the headset away from high-temperature devices while charging.6. Turn off the power switch when left unused for an extended period. <p>These charging instructions apply to all chargeable devices (keyboards/mice/earphones/speakers/etc.).</p>
--	---