

thinkplus头戴式蓝牙耳机 TH10



使用说明书  
使用前请阅读使用说明书

Lenovo

产品功能参数:

蓝牙版本 : V5.0  
 电池容量 : 300mAh  
 充电时间 : 约2.5小时  
 待机时间 : 约 100 小时  
 蓝牙范围 : 10 米  
 喇叭阻抗 : 32 欧姆 ± 15%  
 频率范围 : 20Hz-20KHz  
 喇叭尺寸 : 40mm  
 喇叭灵敏度 : 110dB ± 3dB  
 麦克风灵敏度: -42dB ± 3dB  
 额定输入 : 5V 500mA  
 音频接口 : AUX  
 播放时长 : 约9小时

充电方法:


耳机低电量时: 会发出低电量提示音, 此时需要给耳机充电;  
 充电过程中: 红色指示灯亮起  
 充电完成: 指示灯熄灭

产品使用注意事项

- 除说明书有特别标示的操作方式以外, 请勿尝试拆卸或更换产品内的任何零件;
- 请勿将产品放入水或其他任何液体中, 此产品非防水设计;
- 如果有任何液体不小心进入产品内时, 请立即断开连接并移开此产品。
- 为避免触电, 请在安装或卸载产品时, 确保手上没有沾水。
- 请勿将此产品放置于热源附近或直接暴露在火源附近。
- 请勿将本产品放置在有强大电磁力的环境中, 否则会导致产品故障。

物品清单

- 蓝牙耳机 X 1
- 充电线 X 1
- 说明书 X 1
- 音频线 X 1



产品操作说明:

配对:  
 打开耳机“ON”开机;  
 开启智能设备蓝牙搜索蓝牙名称“联想thinkplus-TH10”  
 点击链接成功;  
 (本产品有蓝牙记忆功能, 再次使用只需开启耳机和设备, 自动回连。)

控制 (请参阅下图的详细信息):

1、产品功能按键接口功能图示

- 暂停/播放/接听: 蓝牙连接前: 双击切换中英文提示音; 蓝牙连接后: 双击拨打最近通话
- 短按: 音量加 长按: 下一曲
- 短按: 音量减 长按: 上一曲
- 拨动开机/关机
- 指示灯
- 充电口
- AUX 音频接口
- 麦克风



产品中有害物质名称及含量

部件名称	有害物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
印刷电路组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表格依据SJ/T 11364的规定编制。  
 ○: 表示该有害物质在该部件所有均质材料中的含量均在GB/T 26572 规定的限量要求以下。  
 ×: 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T 26572 规定的限量要求。  
 表单标记“X”的部件, 皆因全球技术发展水平限制而无法实现有害物质的替代。

印刷电路板组件\*: 包括印刷电路板及其零部件, 电子元器件等, 根据产品型号不同, 您所购买的产品可能不会含有以上所有部件

10 在中华人民共和国境内销售的电子电气产品必须标识此标志, 标志内的数字代表在正常的使用状态下的产品的环保使用期限。

保修声明

免责声明  
 本使用手册没有任何形式的担保、立场表达或其他暗示, 本使用手册所提到的产品、规格及信息仅供参考, 内容亦会随时更新于网页, 恕不另行通知。

保修声明:  
 就本文件附随的产品做如下保证: 如产品在您购买日起十二(12)个月(“保修期”)内, 在正常使用情况下因质量瑕疵发生损坏, 能修理的, 免费修理; 经厂家确认无法修理的, 免费更换; 修理或更换后的产品, 在剩余保修期(最短不少于30天)内继续享有保修。购买日以销售发票日期为准; 如无法确定购买日, 则保修期自产品生产日期起按十三(13)个月计算。

如申请保修, 请先致电产品服务热线, 并按我们指示的方式执行。申请保修时, 您需要提供准确、完整和清晰填写的有效销售发票。

- 以上保证不适用于下列情况:
- 超过三包有效期的;
  - 涂改保修卡、产品编码与产品本体不符;
  - 因误用、滥用或不适当的运输、使用、维护或保管而导致的故障或损坏;
  - 因不可抗力(如地震、战争、火灾等)或意外导致的故障或损坏;
  - 拉链、塔扣因受力过大而损坏;
  - 因承载过重造成的脱线或断裂;
  - 任何因尖锐物体造成的损坏;
  - 有烧损或水浸迹象的产品;
  - 因擅自拆改导致的损坏;
  - 产品正常使用过程中发生的老化、脱色、磨损、破裂和其他损耗。

保修声明

11.如产品原有标识标签被更改或损毁, 本保证将失效。产品及随附物料的齐备和外观完好不属于保证范围, 您应在接收产品时当场检验并对任何不符提出异议。

以上保证是我们就产品做出的全部保证, 且仅在中国大陆地区境内适用。本文件的任何内容均不影响根据法律规定不能排除或限制的消费者权益。

服务热线: 400-812-0102

售后邮箱: frank@szeyan.cn

“Lenovo”, “thinkplus”是联想集团所属企业的商标, 提及的其他公司、产品和服务名称可能是其他公司的商标。版权所有 © 2022联想集团所属企业及其许可方保留所有权利。

thinkplus

thinkplus Headphones TH10



User manual  
Please read all instructions carefully and retain for future use

Lenovo

Product Functional Parameters:

Bluetooth : V5.0  
 Batteries : 300mAh  
 Charging time : About 2.5 hours  
 Standby time : About 100 hours  
 Bluetooth range : 10 meters  
 Speaker independence : 32Ω ± 15%  
 Frequency range : 20Hz-20kHz  
 Horn size : 40mm  
 Horn sensitivity : 110dB ± 3dB  
 Microphone sensitivity : -42dB ± 3dB  
 Rated input : 5V 500mA  
 Audio interface : AUX  
 Length of play : About nine hours

Charging method:


When earphones are low power: Will be issued low power tone, at this time need to charge the headset;  
 During charging: The Red Light is on  
 Charging complete: Lights out

Usage Instruction

- Don't attempt to disassemble the unit and change any part, except there is operation method mentioned in the manual.
- Don't expose the unit to liquid, moisture or humidity, since it is not a waterproof product.
- Disconnect the unit with your Bluetooth device and move it to the safe area if the liquid get inside the unit.
- Don't assemble or disassemble the unit to avoid electric shock, if there is water on your hands.
- Don't expose the unit to extremely high temperature or dispose of the unit in fire as it will result in an explosion.
- Don't place the unit in an electromagnetic interference environment to avoid malfunction.

List of items

- Bluetooth headphone X 1
- Charging cable X 1
- Instructions X 1
- Audio Cable X 1



Product instructions:

pairing:  
 Method 1: Turn ON the "ON" and turn ON the phone.  
 Method 2: Open Smart Device BT Search BT name "联想thinkplus-TH10" Click the link successful;  
 (This Product Has BT memory function, just turn on the earphone and device, and automatically connect back)

Function description

1. Product function key interface function icon

- ① Stop/play/receive: Before connecting to bluetooth: double-click to switch between Chinese and English mode. Bluetooth connected: it will make the latest call.
- ② Click: Turn it up Long press: next Song
- ③ Click: Volume Reduction Long press: Last Song
- ④ Unplug power on/power off
- ⑤ Indicator light
- ⑥ Charging port
- ⑦ AUX audio interface
- ⑧ Microphones



Name and content of hazardous substances in products

Part Name	Harmful materials					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit assembly	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○

This form is compiled in accordance with SJ/T 11364.  
 ○: Indicates that the content of the hazardous substance in all homogeneous materials of the part is in Below the limit requirements specified in GB/T 26572.  
 ×: Indicates that the content of the hazardous substance in at least one of the homogeneous materials of the part exceeds the limit requirements specified in GB/T 26572.  
 The parts marked with "X" on the form cannot be replaced by hazardous substances due to restrictions on the global technological development level.

Printed circuit board components\*: including printed circuit boards and their parts, electronic components, etc., Depending on the product model, the product you purchased may not contain all the above components

10 Electronic and electrical products sold in the People's Republic of China must mark this Logo, the number in the logo represents the product under normal use environmental protection use period.

Warranty statement

Disclaimer  
 This user manual does not have any form of guarantee, position expression or other implication.  
 The mentioned products, specifications and information are for reference only, and the content will also be updated on the webpage at any time, without additional line notification.

Warranty statement:  
 The product attached to this document is guaranteed as follows: If the product is twelve (12) months from the date of purchase ("Warranty Period"), under normal conditions of use due to quality defects damaged, can be repaired free; if the manufacturer confirms that it cannot be repaired, free replacement; repaired or replaced product, Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days). Purchase date by sale The ticket date shall prevail; if the purchase date cannot be determined, the warranty period shall be 13 Months calculation. If you apply for a warranty, please call the product service hotline first and execute it in the manner instructed by us. When applying for warranty, you need to provide an accurate, complete and clearly filled out valid sales invoice.  
 The above guarantee does not apply to the following situations:

- The validity period of the three packs is exceeded;
- Alteration of the warranty card and product code does not match the product body;
- Causes caused by misuse, abuse or improper transportation, use, maintenance or storage impaired or damaged;
- Failure or damage caused by force majeure (such as earthquake, war, fire, etc.) or accident bad;
- The zipper and buckle are damaged due to excessive force;

Warranty statement

- Disconnection or tearing caused by excessive load;
- Any damage caused by sharp objects;
- Products with signs of burning or flooding;
- Damage caused by unauthorized disassembly;
- Aging, discoloration, abrasion, rupture and other losses occurred during normal use of the product.
- If the original identification label of the product is changed or damaged, this guarantee will become invalid.
- The completeness and appearance of the product and accompanying materials are not within the scope of the guarantee. You should Check on the spot and raise objections to any discrepancies.

The above guarantees are all guarantees we make regarding the products, and are only applicable in mainland China. Nothing in this document affects consumer rights that cannot be excluded or restricted under the law profit.

Service supervision hotline: 400-812-0102

After-sales service Email: frank@szeyan.cn

“Lenovo”, “thinkplus” and other Lenovo logos are Lenovo Group The trademark of the affiliated company. (This material) mentioned other trademarks, company names, products or services The name may be a trademark of a Lenovo Group company or another company. Copyright © 2022Lenovo (Beijing) Co., Ltd. All rights reserved.

thinkplus